



MODEL SPECTRA MAX V.3 SERIAL # 2006-8899999

2270 Industrial boul. , Montreal (Laval), Canada, H7S 1P9 Tel.: (450) 667-9769, Fax: (450) 667-6320



INSTRUCTION MANUAL

FOR ALL INQUIRIES PLEASE CONTACT OUR LOCAL DISTRIBUTOR

FOR NORTH AMERICA ONLY 1-800-333-6556 Thank you for choosing ORION stretch-wrapping equipment. It is a wise choice, which will benefit your company now and in the future.

ORION uses a unique combination of functional, rugged steel structure and sophisticated control systems to offer equipment high in durability and low in maintenance requirements. Our advance control systems mean that Orion equipment can be operated safely and efficiently without the need for special operator expertise.

Please read this manual carefully and keep it handy. Following these simple operating instructions will insure the safe and efficient performance of this machine while simple maintenance procedures will guarantee a long and productive life of the equipment.

Notice:

Our manual covers standard features of the machine. Certain options may not be fully covered due to their unique application.

In order to acquire more information about custom made features of your machine and to provide quicker service, the following information is required when making an inquiry:

1)Model

2)Serial Number **2006-8899999** 3)Subassembly (see PART LIST)

SAFETY:

ORION'S stretch wrappers should be operated with caution and common sense as any other industrial equipment. To prevent injury and/or electrical shocks, careful operation of the machine and awareness of its many automatic functions is required.

NOTE: All electrical power and compressed air <u>must to be disconnected</u> prior to all inspection, maintenance or repair work.

ORION PACKAGING INC.

SpectraMAX

Spiral Low Profile Platform Automatic Rotary Turntable System

Maximum Load Size	52"W x 52"L x 90"H
Minimum Load Size	30"W x 30"L x 10"H
Weight Capacity	5,000 lbs. Dynamic, 20,000 lbs. Static
Utilities	115/1/60 20 Amp Electrical Service, 3 CFM Compressed Air @ 80 PSI
Turntable & Drive:	65" Diameter x 3/8" Steel Plate 0-14 RPM variable speed with adjustable soft-start Dynamic positive alignment home positioning feature Chain & sprocket drive with automatic, self-adjusting chain tensioner In-line helical gear reducer on turntable drive train No-maintenance, quiet DuraGlide™ support bearings 3" Height floor to top of turntable
Control Features:	State-of the-Art Allen Bradley MicroLogix Programmable Logic Controller User Friendly Controls with Non-Proprietary Pushbuttons, and Switches Insta-Sense™ Film Broken /Out Sensing Logic with Indicator Light Lanyard Switch for Customer Installation to Allow Remote Cycle Start AUTOMATIC film attachment to the load and cut off RevoLogic™ Exact Wrap Counting To Eliminate Film Waste Electronic Film Tension Control Adjustment on the Panel End of Cycle Film Force Release Separate Top and Bottom Wrap Count Selectors Variable Speed & Separate Film Carriage Up/Down Controls Film Carriage Raise/Lower Switch (Manual) Turntable Jog Pushbutton Cycle Pause for Stopping the Wrap Cycle Without Resetting All Colors Compatible Photocell for Automatic Load Height Detection
Film Stretch & Delivery:	Uses standard 20" film rolls InstaThread for ultra-fast drop-in film threading 260% Standard film stretch (available from 100% to 425%) AUTOMATIC electronic non-contact film force-to-load control Dynamic dancer bar for consistent film tension around entire load Precision ground, polyurethane stretch rollers with lifetime warranty
Film Carriage Drive:	Heavy Duty Zero-maintenance industrial belt lift carriage Variable Speed Drive Motor UHMW Precision Carriage Guidance System
Structural Features:	All STEEL base frame and tower construction Base structure includes dual full-length steel channels Forklift portable from front or rear of machine Hinged tower for ease of transport (reduces machine profile) Adjustable, foldaway film roping bar to lock load to pallet
Film Tail Treatment:	Pneumatic Film Clamping Device Impulse Wire Film Cutting Pneumatic Load Seeking Film Tail Treatment System Folding Film Clamp For Short Loads Wrapping Capability
Ease of Use and Safety:	Fail-Safe film carriage drive with free-fall prevention Film carriage features obstacle detection with automatic shut-off Ergonomic side facing film replacement Protective cover over powered prestretch rollers All-enclosed chains & electronics Protective barrier for film tail treatment device No operator involvement required for film attachment to the load and cut off

ORION PACKAGING RESERVES RIGHTS TO CHANGE THIS SPECIFICATION AT ANY TIME WITHOUT NOTICE

MACHINE UNLOADING INSPECTION & INSTALLATION

UNLOADING

Machine can be easily unloaded and transported by a forklift with a minimum capacity of 2500 lbs.

1. Carefully insert the forks into the lifting tubes to the maximum possible depth. Depending on the model, a forklift access may be either at the turntable end of the machine frame, the tower end or both. In case of the mongoose machine enter the forks under the frame or insert the forks in the tube brackets welded to the top of the machine.

2. Lift the machine (or other part of system) only to the necessary height to move it with no bouncing or friction on the floor.

3. Sit the machine down assuring uniform contact with the floor, which is necessary to ensure correct and smooth operation.

INSPECTION

1. Remove all packing and supporting additions - these may include the blocks under the carriage and the restraining bar over the table.

NOTE: when removing the stretchwrap film covering the machine, care must be taken not to cut <u>any of the electrical wires and/ or polyurethane covering on the film carriage rollers.</u>

2. Perform a visual inspection of the electrical and mechanical parts for loosened joints and / or broken connections. Any suspected shipping damage must be reported immediately to the freight carrier. Any transport damage cannot be claimed to Orion Packaging Inc.

Items that are vulnerable to damage and must be inspected are as follows:

- Motors and transmissions
- Junction boxes
- Electrical conduits
- Proximity and limit switches
- Photocells

3. Check under the turntable to ensure that there is no crippling of the movable parts i.e. casters, center axle or drive assembly.

4.Verify the following:

- Turntable or rotary arm drive system to confirm that the reducer to drive the chain is snug and properly aligned.

- Verify the wires tight conduits for crushed sections or loose fittings.

- Verify the film carriage to be sure that it is correctly aligned with the tower

- Verify the tension on the lift chain.
- Verify all the dials and knobs on the control panel for smooth action.

MACHINE INSTALLATION

After the visual inspection has been completed, the electrical power and the compressed air shall be connected as specified on the diagrams supplied with the machine.

An electrical diagram is provided with each machine in the envelope attached to the panel box.

ASSEMBLY PROCEDURE

The structural frames of the machine have to be installed on a leveled floor.

Locate the main wrapper section into its final position, keeping the tower assembly* away from any traffic.

The wrapper mainframe section **must be bolted to the floor by the 1/2**" concrete floor **anchors** (leg & shield or expandable type).

Any wiring that has been disconnected to facilitate transport is marked with a number located on the junction box to which the wiring must be reconnected. Any wire run that appears too short or long may indicate that the position of the mechanical components is incorrect. Verify the status of all assemblies before proceeding.

* The tower deviation from vertical must not exceed 1/4" on the distance of 10 feet (angle: 0 degrees 6').

The roping bar

The roping bar is rotating around the shoulder screw (dwg M435381 item # 7) and his height can be adjusted from 0 to 6 inches from the base. That device is squeezing a stripe from 0 to 6 inches of the film like a rope to stabilize the load itself or attach it on the pallet. To adjust the roping bar you need a $\frac{1}{2}$ " wrench and you have to loose up the screw #5 and #6.

Getting started

Security tip

Be careful to never walk on the turntable it could cause you an injury.

Put a pallet on the turntable and attach the end of film around the load on the same side than the control panel. Put the carriage at the bottom end of the tower to begin a cycle of wrapping. After the start don't stay to close and wait until the end of the cycle.

After the cycle, cut the film and remove the load. The carriage is returned back to the bottom of the tower and ready to wrap again.

Machine operation and security

Installation of a roll of film

The film roll can be loaded on the carriage mandrel from either end of the roll. When using tacky film, please verify that the inward tacky surface of the film is inward on the load.

1.Disconnect power (turn off power switch).

- 2. Swing up the top mandrel spool.
- 3. Put the roll of film on the bottom mandrel.

4. Install the top mandrel on top of the roll to prevent upward movement.

5. Release the lock and pull the handle to open film distributor cradle.

6. Pass the roped tail of the film through opening (as shown on the film quick threading pattern DWG. # 434460 Fig.1).

7. Close the film distributor cradle.

8. When the film distributor is completed (fig. 2) - turn the power switch on.

9. Peel off the first few winds of the film (multistrech will run due to displacement of the dancer roller) and fix the film end onto the load.

The system is now ready to begin the first wrapping cycle.

Broken film

Open the cradle, pull a few winds of film, close the cradle and the machine is ready to wrap again.



ADDITIONNAL SPACER WASHER

(IF NEEDED ONLY)

The roll of film may be slightly different from time to time, so you might have to change the bottom spool spacer (washer). The only thing you have to do is to add or remove the spacer washer under the bottom spool. With the machine their is 1 washer under the bottom spool (432322), and you have received with the machine 2 extra washer to be use if needed.

<u>Note:</u> The bottom of the film should not be lower than the chamfer of the aluminum strip as shown on the drawing below.







BACK PLATE



FRONT PLATE





MACHINE MAINTENANCE

All general information about machine maintenance is based on normal machine working conditions: indoors, moderate dust and low moisture environment, and maximum rotation of 32 RPM of turntable/rotary arm.

They should be regarded as guidelines, reviewed and corrected according to requirements of actual use and conditions.

MOTOR MAINTENANCE

An occasional inspection of the brushes should be made in order to establish a wear rate. Replacement brushes should be installed before old brushes wear to 9/16" long, measured on the long side. After replacing brushes run the motor near rated speed for at least I/2 hour with no load to seat the new brushes.

Failure to properly seat the new brushes may cause commutator damage and rapid wear of the new brushes. If the commutator becomes rough, scored or out of shape, a competent motor shop should disassemble it and resurface the commutator.

With every third brush change, have a competent motor shop resurface the commutator and blow the carbon dust out of the motor.

REDUCER OIL CHANGE

All external cap screws and plugs on the reducing transmission should be checked for tightness after the first week. It is recommended to change the oil every six months or at least 1800 hours of operation, whichever comes first. When adding or changing oil, the transmission should never be filled above the oil level mark indicated, because leakage and overheating may occur. Below is the list of the type of lubricant that should be used.

List of recommended reducer oils

Manufacturer

American Oil Co.. Cities Service Oil Co. Gulf Oil Corp. Mobil Oil Corp. Philips Oil Corp. Texaco Inc. Shell Oil Co. Union Oil of Cal. Lubricant

American Cyl Oil no: 196-L Citgo Cyl Oil 100-5 Gulf Senate 155 Mobil 600 W Suer-r Cyl. Oil Andes S 180 624 + 650T Cyl.Oil Velvata Oil J82 Red Line Worm Gear Lube 140

RING BEARING MAINTENANCE (when applicable)

The ring bearing (located under the turntable) should be re-lubricated internally and externally.

Internally: by injecting grease into all the lubrication nipples in succession until a collar of fresh grease appears around the perimeter of the ring. The re-lubrication interval suggested for these bearings, used in Stretch Wrapping Machinery is 750 hours, with a maximum period of 6 months. The lubricant should be fresh and applied in sufficient quantities to make sure all surfaces are lubricated.

Externally: by lubricating and wiping the chain drive with oily cloth. The frequency of lubrication depends on entirely upon the usage of the machine and environment in which the machine is placed (dust, moisture etc.).

Machines working under extremely dirty conditions should be lubricated every 400 operating hours but at minimum, every 2 months. Longer lubrication intervals may occur only when machine is working under very clean and dry conditions but should be not be longer than 6 months.

List of recommended lubricants for the ring bearing lubrication

Manufacturer	Lubricant
BP Castrol Esso Gulf Mobil Shell Texaco Valvoline	Energrease LS2 Speeroll AP2 Beacon 2 Crown Grease 2 Mobilus 2 Avania Grease R2 Glissando FT 2 LB-2
valvoline	LD-2

TOWER RACEWAYS MAINTENANCE

The film distributor (carriage) is sliding on the plastic guides attached behind its back plate. The section of the tower on which the plastic guides move (raceways) should be cleaned and re-greased approximately every 600 hours of machine operation.

NOTICE: If the machine works in a dusty and corrosive environment, the raceways should be re-greased more often (at least every 100 hours).

CHAIN MAINTENANCE

To clean the chain, wipe it with an oily cloth every month. When machine is working in a dusty and damp environment, it may be necessary to repeat the cleaning operation more often. As the chain lubricants please use the most common chain lubricants on the market. With time, the chain will tend to stretch. A loose chain should be tightened at the chain tensioner, or by moving the reducer on its mounting plate.

NOTICE: Chain tension first adjustment must be done after the first <u>two weeks of machine</u> <u>usage.</u>

PNEUMATIC SYSTEM MAINTENANCE (when applicable)

The air supply system must be checked weekly and must be free from the moisture. In cold environments, it may be necessary to drain the air supply system daily.

CAM FOLLOWER MAINTENANCE (when applicable)

The cam followers have deep grease pockets and do not need frequent relubrication. The portion of the tower on which the cam followers run, should be cleaned and regreased every 300 hours of operation. If the machine operates in a dusty or corrosive environment the tower should be relubricated more often.

SEMI-AUTOMATIC STANDARD ASSEMBLY PART LIST

Note : * Quantity listed in order of part number ** The names given to the parts are generic



•	DESCRIPTION	Length/In	SIZE	PART No.	Q'ty	WEIGHT
		,	DWR		/	
	LPA-BASE ASSEMBLY			443642	1	
	LPA-TOWER ASSEMBLY			443544	1	
	LPA-FILM TAIL TREATMENT			44 <i>333</i> 6	1	
	FILM TAIL TREATMENT GUARD			443360	1	
	INSTA-THREAD-FLR-20			443591	1	
	BACK TOWER STOPER			436790	1	
	ROPING BAR ASSEMBLY			443608	1	
	POWER TRACK K20-4			015897		

	"SPECTRA I		WRAPP	'ER		
	TOLERANCES Unless otherwise specified	drawn by: V. <i>Telebak</i>	DATE: JAN-17-2003			
	MACHINED: ±1/64	Checked By; —	TOTAL Weight _	DWG. Size: <i>B</i>		
170 industriel, laval Iebec, canada, H7S 1P8 1.; (450) 687–9769	WELDED: ±1/32 ANG.:±1/32 PER 60"		ence dwc. 1309	SCALE: 1 : 24	Ω-TΥ 1	
	ASSEMBLY DVC	JOB ND.: STD	DWG Na.: 4	4 <i>3</i> 641M	^{rev.} A	

	E ORINI PACINGING INC.
14 SHOLLDER SCREW 13 HEX SCREW 12 HEX SCREW 12 HEX SCREW 11 RAM WASHER 10 BASE COVER 9 GAMN TIGATENER ASSEMBLY 9 GAMN TIGATENER ASSEMBLY 9 GAMN TIGATENER ASSEMBLY 9 GAMN TIGATENER ASSEMBLY 10 GAMN TIGATENER ASSEMBLY 11 Interview Cover	N: TELEBAK ₩12: JAVI-18-2005





				1				
8	HEX HEAD SCREW			016112			3	
7	HEX HEAD SCREW			014668			3	
6	FLAT HEAD SCREW			013842			3	
5	RING-BEARING			017801			1	
4				443316 A			1	
3	SPECIAL HEX HEAD SCREW			443315 A			8	
2	SPECIAL SOCKET CAP SCREW			443314 A				
1	SPROCKET			44331.3 A				
ITEM	DESC	ription		FILE, PAR	IAL of	y weight e poids		
	LPA-T.T. RING	G-BEARING A	ISSEMBL	İΥ	Α	scale: echelle: 1.6	poids t	/Eight-lbs Otal-lbs;
			DRAWN BY: DESSINE PAR	ROGER F.		date: Mar-d4-2004	7 <i>6</i>)
6	orion	$ \oplus \Box$	ass'y owc:	443310 B		Wachine Type: S-Max	O'TE:	1
OL OL	Fackaging inc. 70 Industriel, Laval Xebec, Canada, H75 1P9 L: (450) 687–9769	Tol. ; ± 1/32 or ±.010 Unless otherwise Specified	JOB No:	13786		44	13312	2М

3

4

T

 \sim







	act. 00001			047007						1
8	SET SCREW			017987					4	
7	MALE CNNECTOR			011986					2	
6	SWIVEL MALE ELBO	W		017630					6	
5	SOCK.SCREW			017367					1	
4	External retainin	IG RING		013655					1	
3	3 D-RING			017933					5	
2	4 PASSAGES ROTORSEAL SHELL			44.3322 A					1	
1	4 PASSAGES ROTO	RSEAL CORE		443321 B					1	
ITEN	DESC	RIPTION		FILE,PAR	ΤN	0. OR	MATER	IAL	O'TY Q'TE	Weicht Poids
	4 PASSAGES	ROTORSEAL			A	SCALE: Echelle:	1:2	tot/ Poie	AL WEK	HT-LBS: NL-LBS:
			DRAWN BY: Dessine par:				5-2004		-	
0	or loin	$\square \oplus \square$	ASS'Y DWG: 44	43310 B		Maghine type: S-max		0'TE	1	
l qu	PACKAGING INC. 70 INDUSTRIEL, LAVAL EBEC, CANADA, H7S 1P9 ; (450) 667-9769	TDL. :± 1/32 OR ± .010 UNLESS DTHERWISE SPECIFIED		13578	I		4	.43	320	DM

CE DESSIN EST CONFIDENTIEL ET NE DOIT PAS ETRE REPRODUIT OU UTILISE SANS LE CONSENTEMENT DE ORION PACKAGING INC.



DOIT PAS ETRE REPRODUIT OU UTILISE SANS LE CONSENTEMENT DE ORION PACKAGING INC. 띧 Б DESSIN EST CONFIDENTIEL 띵

		3		2)
5 SCREW		011366	1	
4 SHQULDER SCREW 3 SPRING		015122 017284	1	
2 IDLE SPROCKET		017204	1	
1 CHAIN TIGHTENER ARM		430035	1	
No. DESCF	RIPTION	size PART No.	Q'ty V	NEIGHT
REMARKS:			1 - 1	
Remarks:				
CHA	AIN TIGHTENER ASS			
	DATE: APR-13-2004	SCALE:	1:4	
	DRAWN BY: <i>ROGER F</i> .	MACHINE TY		
PACKAGINC INC. 2270 INDUSTRIEL, LAVAL DUEBEC, CANADA, H7S 1P9 TEL.: (45D) 567-9769	CHECKED BY:	DRAWING SI	ze: A	
ASSEMBLY DWG.: 430002	JOB No.: —	Drawing No	441(783M













6	VL LMIT SWITCH					-	- 2	
5	LOCK WASHER					01139	0 2	
4	HEX SCREW					<i>Q1247</i>	4 2	
2	NUT FLAT					01785.	3 2	
2	LINIT SWITCH BRACKE	7				<i>44323</i> ,	3 2	
1	CHANNEL					44323	2 1	
No.		SCRIPTION		Length/In	DWG. Size	PART I	No. Q'ty	WEIGHT
REMAR								
REMAR	2							
	BOTTOM	LIMIT SWITCHES	ASS'Y					
-		TOLERANCES Unless dtherwise specified		s. Kubicka		DATE		08-2004
0	PACKAGING NC. D INDLISTRIEL, LAVAL	MACHINED: ±1/64 WELDED: ±1/32	CHECKED B	-		TOTA Vieig	с нг_	dwg. Size: A
9 EL	BEC, CANADA, H7\$ 1P9 ; (450) 667—9769	ANG.: ± 1/32 PER 60"	-		VG #		E, 1:4	о-тү 1
PROJE		Assembly dwc.: 44.3227 B	108 No.:	13578	DWG N	^{••} 443	231M	REV. B









						_					
5	LOCK WASHER					011390	1				
4	HEX SCREW					012474	2				
3	NUT FLAT SQUARE				017853	1					
2	LINIT SWITCH BRACKE	7				443233	1				
1	CHANWEL					443232	1				
No.	DES		Length/kn	davig. Size p	ART Na.	۹ˈty	WEIGHT				
REMAR	REMANCE:										
REMAR	a:										
	top limit	t switch ass'y									
1		TOLERANCES Unlebs otherwise specified	B S. KUBICKA DEC-03-					13-2004			
0	PACKAGING INC.	MACHINED: ±1/64	CHECKED &	CHECKED BY:			TOTAL Veight _				
00E	5 NOLISTREL, LAVAL Bec., Canada, H75 1P9 : (450) 667–6769	WELDED: ± 1/32 ANG.:± 1/32 PER 60"	VACHINE TY 5-	ne referei - <i>NIAX LON</i>	ice dirg. IG <i>#</i>		: 4	D-1Y -			
PROJE	°®: ⊕⊖	ASSEMBLY DINC.: 44.3227 B	JOB N4.:	13578	DWG No.:	4432	34M	REV. A			





7	SELF SEATING EXTERNAL RETAINING RING				03	4	
6	CRS SHAFT			-		1	
5	CRS SHAFT			-		1	
4	EXTENSION SPRING			4031	18	1	
3	BELT ROLLER			4364	21	2	
2	BEARING PLATE			4300	22	2	
1	BELT IDLER ROLLER BRACKET			4364	20	1	
No.	DESCRIPTION				No.	Q'ty	WEIGHT
REMARK	S:						
REMARK	<s:< td=""><td></td><td></td><td></td><td></td><td></td><td></td></s:<>						
	BEL	T IDLER ROLLER A	SS	EMBL	Y		
		DATE: NOV-19-2002		SCALE	3	1:	4
		RDGER F.		MACHI	NE TY	ре: 5/ ² -	-2.1
	2270 INDUSTRIEL, LAVAL CHECKED BY: QUEBEC, CANADA, H7S 1P9 TEL.: (450) 667–9769				NG SIZ	A	
ASSEN	BLY DWG.: <i>436404</i>	јов №= 12812		DRAW	NG No		641 <i>3M</i>













PROJE	™⊕⊖	ASSEMBLY DWD:	JOB No:	STD	DWG N	•" 44 <i>3</i> 44	1M	™.A
quee Tel.:	PACKACING INC. DI NDUSTRIEL, LAVAL BEC, CANADA, H79 1P9 : (450) 867-9769	MACHINED; ±1/64 WELDED: ±1/32 ANG.:±1/32 PER 60"		– NAX 430	5414	1	- : 4	SIZE: Д Q-ТҮ —
0		unless otherwise specified	CHECKED BY	NARIA MIER r:	NIK	TOTAL	ÆС-2	0-2004 DND.
		ARRIAGE BELT L	DR/VE			DATE:		
REMAR	_							
REMAR	-			1			1	1
No.	DES	SCRIPTION		Length/In	DWC. Size	PART No.	Q'ty	WEIGHT
1	REDUCER BRACKET					4 <i>36439</i>	2	
2	BELT WHEEL					430024	1	
3	REDUCER					010986	1	
4	ELECTRIC MOTOR					015225	1	
5	HEX SCREW					012724	4	
6	KEY LOCK WASHER					010295 012724	1	
8	PLASTIC CONNECTOR			010550-1	1			
9	NUT LOCK					010650-2	1	
10	WASHER SEAL					010850-3	1	











S HEX HEAD SCREW 012475 2 4 HEX NIT 011128 1 3 HEX REW 011656 1 2 ROPING BAR 143810 2 1 ROPING BAR 443501 2 1 ROPING BAR 443608 1 No. DESCRIPTION Length/In 104800 1 No. DESCRIPTION Length/In 1047 104102 NURS TOLEMARES WILLES ORHINGS 101128 1 NURSTRILLUM, INTER NO. DESCRIPTION Length/In 1040 NURSTRILLUM, INTER NO. DESCRIPTION Length INTER 10400 1070 NURSTRILLUM, INTER NO. NO. 1012000 1070 104000 NO. INTELEMARE INTELEMARE INTELEMARE 107000 107000 107000 NO. INTELEMARE INTELEMARE 10700000000000000000000000000000000000

APPENDIX

Multistretch Interface Board Calibration Instructions For MIB-336 Interface Board.

Adjustments:

Gain; The Pot controls the system Gain.

This control injects an offset voltage, which adds or subtracts from the voltage reference defined by the External Tension Adjustment (Film Tension Potentiometer); this will allow extremes of adjustment to be set to levels consistent with proper operation. Typically, the Gain will be used to center the operating range in linear portion of its characteristics.

<u>Note:</u> This adjustment is normally made at the factory and should not require fields adjustment.

Zero: The Pot controls the system loop gain.

This system loop gain may be adjusted if the motor continues to be energized when the dancer arm is unloaded and at rest. With the machine stopped, the potentiometer should be adjusted to ensure that the motor is de-energized in this condition, and so that a light pull on the free end of the film causes the film to feed freely. Counter clockwise (CCW) adjustment of this potentiometer will increase the response time i.e. (soften the motor tension response). Clockwise (CW) adjustment decreases the response time i.e. (sharpen the motor response) plus increases the maximum possible motor speed attainable.

<u>Trip:</u>

The output relay located on MIB-336 Board (Outputs: Com (14); NO(13); NC(15)) energized when the voltage between (11) & (12) overshoots the level selected on the potentiometer marked "Trip". It de-energizes when the voltage falls below the normal current by approximately 5% or when power to board breaks.