

## Installation of Anti-Static Kits

When installing the anti-static cord, open the film carriage and attach one magnet on the top of roller holder. Move the film so the cord can be placed behind the film and attach the other magnet to the bottom roller holder. Close the film carriage and position the cord so it is 1/8" from the film, to allow the film to run in front of the cord to reduce static. Refer to the photos below for correct installation.

- 20" Anti-Static Kit – Part# 0369290
- 30" Anti-Static Kit – Part# 0369291

